

LO PRO MOORING COVER MOUNTING INSTRUCTIONS

1. Stretch out cover and pull tight to four corners, clamp with padded vise grips or have someone help hold down corners. Check all around for fit.
2. Use a drill with Phillips #2 bit and install all corners first. Snaps are self-drilling.
3. Mark for drilling with felt pen and install remaining snaps, always working from the center point between two snaps.
4. Locate loops in back by motor for attaching stretch cord around motor. Locate where the stretch cord is pulling down and in.