



Paddle Boat Trailering Bow Eye Installation

1. Locate the Center bar between the foot pedals (The chain guard is attached to this)
2. Using a tape, measure 2-1/4" from **A**
3. Using a 3/8" drill bit, drill a hole completely thru the square tubing centered at the 2-1/4" mark
4. Insert bow eye with bolt thru the drilled hole from the topside.
5. Vertically position the Bow Eye.
6. Add washer and nut to the underside. Tighten using 9/16" socket and ratchet.
7. Tighten until bolt is tight and there is no visible gap between the bow eye and the frame. The spike teeth will pierce into the metal, so be sure that the bow eye is correctly positioned before tightening.

