



New Canopy Mounting Rail Deck Hinge Brackets for a Lo Pro

1. Measure 7" from the backside of the rear wall to the center of the pin hole on the deck hinge bracket to place the rear deck hinge
2. Use the pre-drilled holes that are already in the deck hinge to drill the deck hinge to the frame
3. Measure 28 5/8" forward to the center of the pin hole for the middle deck hinge
4. Use the pre-drilled holes that are already in the deck hinge to drill the deck hinge to the frame
5. Measure 27 7/8" forward to the center of the pin hole for the front deck hinge
6. Use the pre-drilled holes that are already in the deck hinge to drill the deck hinge to the frame
7. The two larger pins (snap pins) will be for the rear deck hinge brackets that are drilled to 5/16" hole
8. The two smaller pins (detention pins) are for the middle and front deck hinge brackets depending on the positioning of the canopy.

The two larger pins (snap pins) are for the rear brackets that are drilled to 5/16".

Please note: If you are having troubles getting the rear pin in the hole, drill the hole with a 5/16" bit to widen it for a better fit.