



Scan for video



Paddle Boat Mooring Cover Installation



Snap screws will be installed just above the first ripple on the side trim. The back of the boat the snap screws will be installed on the aluminum bar just below the deck.

NOTE: Self-tapping snap screws are intended to be self-drilled into aluminum.



Tools needed:

1. Impact driver or electric drill
2. 2# Phillips bit
3. Optional: Chalk for marking

Installation

1. Put mooring cover on the paddle boat with the Paddle King tag being in the front center of the boat. Be sure the cover reaches all four corners.

(Snap each mooring cover snap after installing the snap screw)

(Install the four corners first before the middle snaps)

(Optional: Use chalk to mark where a snap screw need to be installed)

2. Start by installing snap screws into one of the front corners. Then do the opposite corner on the back.
3. Install the other front corner and then install the last rear back corner.
4. Install the remaining snap screws in the front, rear, and sides.
5. When removing the cover, unsnap each snap—don't yank a whole row off with one pull—this could loosen the snaps or tear them off completely and damage your cover.

Mooring Cover Maintenance

The cover should be cleaned once a year using a mild soap and water with a soft-bristle brush. Allow the cover to dry completely and apply a UV inhibitor product for vinyl such as 303 Aerospace Protectant. 303 Also makes a good cleaner as well. Apply petroleum jelly or WD-40 on the snaps (on the boat) to keep them working well. Please feel free to contact us at Paddle King if you have any questions.