



Paddle Boat Mini Mooring Cover Installation



Tools needed: Drill or impact driver with a #2 Phillips bit.

WARNING!!! ALWAYS CUP HANDS AROUND BIT AND SCREW WHILE INSTALLING TO PREVENT THE BIT FROM DAMAGING YOUR SIDE SKIN IN THE EVENT OF THE SCREWS SLIPPING.

Step 1: Put mini mooring cover on the boat.
The velcro flaps go around the canopy mounts. Smaller flap towards the back.





Step 2: Install the self-drilling snap screws into the aluminum frame of the dog house starting with the front. Be sure to install the snap screws where the snaps are on the mooring cover.



NOTE: You may have to lift the seat cushion flap up slightly to install screws.

Step 3: Install the snap screws on the back. Lift up the seat cushion flap to install the snap screw.



Step 4: Install the snap screws on the sides. These screws go into the foot of the seat back.

