



PEDAL EXTENSION INSTALLATION

You will need a Philips #2 screwdriver. Do NOT over tighten screws during the process.
New screws provided with pedal extenders.

1. Remove your existing pedals (to be used later)
2. Place half of the existing pedal on the pedal extension piece and snap together
3. Insert the 1 3/4" screws and tighten until snug
Note: the small flange on the inside of the pedals must be opposite of each other
4. Place assembly on the axle and attach the remaining pedal half on the extension assembly, snap together with flanges opposite of each other.
5. Insert remaining screws, tighten until snug



7110 S Crystal Rd, Carson City, MI 48811

989-235-6776